



• No. OC-3500 DIAGRAM



• No. OC-3505W *DIAGRAM*



PARTS LIST

- Left Side Cover Ass'y Spool Tension Shim
 - Ball Bearing
- E.C.lip

- 9 Currier Guide 10 Carrier Ass'y
- Brake Shoe Spool Ass'y Ball Bearing
- Worm Shaft Bush
- 15 E.Clip
 16 Frune
 17 Rekase Slider Spring
 18 Rekase Slider
 19 Rekase Slider
 20 Kick Lever
 21 Kick Lever
 22 Pinion Yoke 13 Worm Shaft 14 Oscillating Gear

 - 11 Line Guide Pawl

- 46 Tension Knob Shim 47 Tension Knob 35 Drag Disc Washer 36 Drag Washer 17 Spring "p" Washer 38 Ibill Hearing 39 Henring Washer 40 Right Holder
 - 42 Right Side Cover Screw

41 Right Side Cover

28 Crank Shaft Retainer Screw 27 Crunk Shuft Retniner

24 Yoke Spring 25 Crunk Shuft Bush 23 Pinion Ass'y

26 E. Clip

32 Rutchet
33 Drive Gear Washer
34 Drive Gear

30 Crunk Shaft 29 Idle Geur

48 Ster Ding 49 Ha odle Spring Washer 50 Harolle Ass'y 51 Ha odle Nut Lock Cap 53 Harolle Nut Lock Cap 53 Harolle Nut Lock Screw 54 Themit Bar 43 Thumb Screw 44 Tension Knob 'Y)" Ring 45 Tension Knob Washer

55 Click Claw Shaft (OC-3505W) 56 Click Claw (OC-3505W)

- 57 E-Clip (oc.3505w)
- 58 Click Claw Spring (RC:3505W) 59 Sound Lever (RC:3505W)
- 60 Sound Lever Spring (CX : 3805W)
- 64 Sound Lever Pin (ex. Nutsw) 62 One Way Clutch Ball Bearing 63 One Way Clutch Ball Bearing Bash